

SYSTEM REQUIREMENTS

ALLPLAN SHARE

HARDWARE/SOFTWARE-REQUIREMENTS

NETWORK

- > An internet connection that is stable and uninterrupted.
- > **Minimum requirements:** 10 Mbit/s for upload; 20 Mbit/s for download, the latency must be less than 50 milliseconds (you can check this by means of Allplan Performance Diagnostics, for example).
- > **Recommended:** 50 Mbit/s for upload; 100 Mbit/s for download, the latency must be less than 10 milliseconds (you can check this by means of Allplan Performance Diagnostics, for example).
- > Current network drivers
- > Network connections based on LAN (better than WLAN)

LOCAL FILE STORAGE FOLDER

- > If possible, use a local (SSD) hard drive for the local file storage folder; network drives slow down access. The local file storage folder must not be shared between several users; this might cause massive problems. The Services window shows the path of the local file storage folder.
- > You can find information on how to change the path of the local file storage folder in a FAQ on Allplan Connect; for example, enter the following search term: "local file storage folder Allplan Share".

HARDWARE

- > The hardware requirements are the same as those for Allplan.

FURTHER REQUIREMENTS

- > You have an Allplan Bimplus/Allplan Connect/Allplan Campus account
- > An Allplan Bimplus team is available
- > To create Allplan Share projects, you have to be the team owner or team administrator of the Allplan Bimplus team
- > You have one or more Allplan Share licenses

